

WARNING

Permanent hearing loss may result from long-term exposure to sound at high volumes. Use as low a volume as possible.

Headsets are capable of delivering sounds at loud volumes and high pitched tones. Under certain circumstances, exposure to such sounds can result in permanent hearing loss damage. The volume level may vary based on conditions and volume settings, and the environment. Avoid prolonged use of the headset at excessive sound pressure levels. Please read the safety guidelines below prior to using this headset.

Reduce the risk of hearing damage by following these safety guidelines:

1. Prior to using this product follow these steps

- Before putting on the headset, turn the volume control to its lowest level;
- Put the headset on; and then
- Slowly adjust the volume control to a comfortable level.

2. During the use of this product

- Keep the volume at the lowest level possible and avoid using the headset in noisy environments where you may be inclined to turn up the volume;
- If increased volume is necessary, adjust the volume control slowly;
- Ringing in the ears may indicate that the sound levels are too high;
- If you experience discomfort or ringing in your ears, immediately discontinue using the headset and consult a physician.
- With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

Safety information!

- Use of a headphones will impair your ability to hear other sounds. Use with caution while using your headset when you are engaging in any activity that requires your full attention.
- Never try to repair the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in damage to the product.
- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact VKTEK SOLUTIONS.